


THE VERTICAL HEIGHT OF THE MULTI-FLOW SYSTEM(6",12",18") AND INSTALLATION DEPTH SHOULD BE CHOSEN BASED ON EXISTING CONDITIONS AND DESIGN CRITERIA ESTABLISHED BY THE ENGINEER.

INSTALL MULTI-FLOW IN THE CENTER OF THE TRENCH. BACKFILL MATERIAL SHOULD BE A VERY COARSE SAND. MIN. RECOMMENDED SLOPE 1%.

### UNDER TURF INSTALLATION


EXAMPLE INSTALLATION





# UNDER PAVEMENT INSTALLATION EXAMPLE INSTALLATION







CART PATH INSTALLATION



TYPICAL MULTI-FLOW INSTALLATION


PATENT 4995759






# CURB AND GUTTER INSTALLATION

EXAMPLE INSTALLATION




UNDER SLAB/FOUNDATION
INSTALLATION
EXAMPLE INSTALLATION




## MEDIAN CURB INSTALLATION

Www.varicore.com

EXAMPLE INSTALLATION




UNDER WALKS/OBSTRUCTIONS
INSTALLATION
EXAMPLE INSTALLATION




## RETAINING WALL INSTALLATION

EXAMPLE INSTALLATION



#### LANDSCAPE TO PAVEMENT INSTALLATION


EXAMPLE INSTALLATION




## HORIZONTAL/SHALLOW DEPTH INSTALLATION

EXAMPLE INSTALLATION





#### TREE WELL INSTALLATION EXAMPLE INSTALLATION



#### SYNTHETIC TURF INSTALLATION

EXAMPLE INSTALLATION